



A graphic element consisting of two yellow, irregular, elongated shapes positioned on the right side of the page. The top shape is oriented diagonally upwards from left to right, while the bottom shape is oriented diagonally downwards from right to left.



Espaço e velocidade

The Microsoft Start menu displays four pinned tiles:

- Weather**: Shows the current temperature in Valley Park, CA, at 72°F (22°C) with a sun icon, indicating strong UV today and 0% chance of rain. A "See full forecast" button is present.
- Microsoft Edge**: A web browser tile with a search bar placeholder "Search the web" and a magnifying glass icon. It shows a thumbnail of a beach scene with a bridge.
- Watchlist**: A financial news tile for WGRB Woodgrove Bank, showing a price of 435.75 and a -1.67% change. It also lists "CTSP Contoso" with a price of 23.98 and a +2.23% change.
- Calendar**: A calendar tile for October, showing the days 20, 21, 22, and 23. An event for "Angela's Birthday" is listed for October 20th, and a "Lunch" event for Alex Johnson is listed for October 23rd.

 Photos

On This Day

Oct 20 · 33 items

See all

In Skype Meeting

6:00 PM Studio Time
3h Conf Rm 32/35

To Do



Design único

A beleza do Aspire 5 aparece em suas linhas finas e no acabamento em metal na tampa com textura de alumínio escovado. Além disso, o desenho e a posição das portas deixam o chassi



A tela de 15,6" IPS traz imagens muito mais vibrantes e realistas, com cores mais vivas e detalhadas. A tecnologia de matriz ativa garante uma visão fluida e sem迟延, mesmo em movimento. O contraste profundo e a luminosidade elevada permitem que você assista a filmes e jogos com uma experiência visual excepcional.


A close-up photograph of the bottom edge of a laptop. The laptop is open, showing the trackpad and the beginning of the keyboard. A green strap is attached to the left side of the laptop's base. The background is white.

A close-up view of a portion of a keyboard, showing the following layout:
Row 1: ~, !, @, #, \$, %, ^, &
Row 2: Tab (with left and right arrow icons), Q, W, E, R, T, Y
Row 3: Caps Lock, A, S, D, F, G, H
Row 4: Z, X, C, V, B, N



Áudio que i

oferecem graves mais profundos e mais volume. Dê vida aos seus vídeos e músicas com uma nitidez de áudio realista.



Transmissä

